


ASSEMBLY INSTRUCTION


DE - MONTAGEANWEISUNG
 FR - INSTRUCTIONS DE MONTAGE
 DK - MONTAGEVEJLEDNING
 CZ - NÁVOD K MONTÁŽI
 ES - INSTRUCCIONES DE MONTAJE
 FI - ASENNUSOHJE

HR - UPUTE ZA MONTAŽU
 SE - MONTERINGSANVISNING
 SI - NAVODILA ZA MONTAŽO
 TR - MONTAJ TALIMATI
 NO - MONTASJEANVISNING
 IT - ISTRUZIONI DI MONTAGGIO


GR - ΟΔΗΓΙΑ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ
 NL - MONTAGE INSTRUCTIE
 PT - INSTRUÇÕES DE MONTAGEM
 PL - INSTRUKCJA MONTAŻU
 HU - SZERELÉSI UTASÍTÁS



20 min




IMPORTANT, RETAIN FOR FUTURE REFERENCE : READ CAREFULLY




- ① HW-ST-01-136 (4 x 20) x 4
- ② HW-ST-02-021 (6 x 20) x 2
- ③ HW-ST-02-290 (8 x 35) x 8
- ④ HW-ST-07-044 (8.5x18x1) x 8
- ⑤ HW-ST-07-044 (8.5x18x1) x 8
- ⑥ HW-ST-01-168 (4 x 17) x 6
- ⑦ HW-ST-04-060 (48 x 30 x 8) x 2
- ⑧ HW-ST-18-001 (4 x 98) x 1
- ⑨ HW-ST-18-007 (13 x 88) x 1


Ⓐ x1
 SU-TB-AS-0349







Ⓑ x1
 SU-TB-TF-1023





Ⓒ x1
 C-A-TB-SU-0889




Ⓓ x4
 SU-TB-LF-1432






I



II



III

